

デジタルビデオカメラ用保護フィルム対応表('11.1.27更新)

サイズ(型)	対応品番(反射防止)	価格	サイズ(mm)	
			W	H
2.5		なし		
2.5ワイド		なし		
2.7ワイド	DG-LC27WDV	¥580	58.0	32.0
2.8ワイド	DG-LC28WDV	¥580	60.5	33.5
3.0		なし		
3.0ワイド	DG-LC30WDV	¥580	67.0	38.0
3.2ワイド	DG-LC32WDV	¥580	70.0	39.0
3.5ワイド	DG-LC35WDV	¥580	80.5	47.5

メーカー	シリーズ	型番	2.5	2.571"	2.771"	2.871"	3.0	3.071"	3.271"	3.571"	
Panasonic		TM750						●			
		TM700						●			
		TM650			●						
		TM350			●						
		TM300			●						
		TM90							●		
		TM85							●		
		TM70				●					
		TM60				●					
		TM45				●					
		TM35				●					
		TM30				●					
		TM25				●					
		SX5				●					
		SD200				●					
		SD100				●					
		SD9				●					
		SD7				●					
		SD5				●					
		SD3								●	
SD1								●			
HS350				●							
HS300				●							
HS200				●							
HS100				●							
HS60				●							
HS9				●							
H80				●							
DX3								●			
DX1								●			
SONY	HANDYCAM	XR550V								●	
		XR350V			●						
		XR150			●						
		VX2100	●								
		TD10								●	
		PJ40V							●		
		PJ20							●		
		NEX-VG10							●		
		HC62			●						
		HC9			●						
		FX1000								●	
		CX700V							●		
		CX560V							●		
		CX550V									●
		CX370V				●					
CX180								●			
CX170				●							
AX2000								●			
CANON	iVIS	HF S21								●	
		HF S11			●						
		HF R21							●		
		HF R11			●						
		HF R10			●						
		HF M43							●		
		HF M41							●		
		HF M32			●						
		HF M31			●						
		HF G10									●
HF21			●								
Victor	Everio	GZ-X900				●					
		GZ-MS230			●						
		GZ-MS210			●						
		GZ-MS130			●						
		GZ-MS120			●						
		GZ-MG980			●						
		GZ-MG880			●						
		GZ-MG840			●						
		GZ-HM990									●
		GZ-HM890									●
		GZ-HM880									●
		GZ-HM690			●						
		GZ-HM670			●						
		GZ-HM570			●						
		GZ-HM450			●						
		GZ-HM400				●					
		GZ-HM350			●						
		GZ-HM200			●						
		GZ-HM1				●					
		GZ-HD620			●						
GZ-HD320			●								
GZ-HD300			●								
GS-TD1									●		
GC-WP10							●				
GC-FM2							●				
SANYO	Xacti	DMX-WH1E		●							
		DMX-WH1		●							
		DMX-SH11			●						
		DMX-HD2000			●						
		DMX-GH1			●						
		DMX-FH11							●		
		DMX-CS1			●						
		DMX-CG110			●						
		DMX-CG100			●						
		DMX-CG11							●		
		DMX-CA100			●						
DMX-CA9		●									